

CHANGING ROOMS & WET AREA FLOORING

SPECIFICATION FOR PREPARATION OF OLD OR NEW FLOOR SURFACES PRIOR TO LAYING TACTILES.

1. When using TactTiles in wet floor conditions it is recommended that floor areas be laid to falls with a drain or gully. Sealing the sub-surface with Special Primer eliminates dust and aids cleaning.
2. TactTiles lie smoothly over most rough areas, readily adopting the contours of a 'wavy' surface. **Major irregularities of level** on old tile / concrete surfaces, can be corrected with the application of Tact Durafloor Self-Levelling Compound to the floor.
3. Remove any oil / grease / fatty deposits in the floor with Tact Bioclean.
4. **New concrete slabs** or screed require one week of time to complete drying, per 25mm of concrete depth.
5. After the concrete has dried thoroughly, wash off any loose aggregate / latence. Sieve or filter to remove this material before the water enters the drains.
6. Allow the floor to dry for a further 48 hours.
7. Mix Tact Poolcoat Primer (5ltr covers approx. 45m²) as per instructions and in correct temp. / humidity criteria.
8. Apply 1st coat of Tact Poolcoat Primer by brush / roller.
9. Apply 1 coat of Tact Poolcoat in areas of regular washing and / or chemical attack / heavy cleaning – poolsides etc.
10. Allow **7 days 'curing' time** before putting floor into service.
11. Lay TactTiles Metro Flooring System 1 day after PoolCoat has been applied.
12. For ease of in-service cleaning see the TactTiles Care & Cleaning instructions.

These notes are for guidance only, please discuss the detail of your application with your Tact representative.